



Quick Install Guide

Wi-R3


1200Mbps Dual-Band Wireless Mesh Router with PoE Passthrough

www.wireless-tek.com


1. Package contents



X1





X1



X1

2. Interface and LED Indicator




WAN/LAN3/LAN2 PoE OUT
LAN1 with PoE IN
DC IN 12V-54V
RESET
PoE OUT Slide Switch

LED	Description
PWR	On: the device is powered up. Off: the device is powered off.
SYS	On: the device is running normally. Off: the device is running abnormal.
2.4G	On: 2.4G Wi-Fi is normally. Off: 2.4G Wi-Fi is abnormal.
5G	On: 5G Wi-Fi is normally. Off: 5G Wi-Fi is abnormal.
2.4G LINK	On: 2.4G has link connection. Off: 2.4G has no link connection.
5G LINK	On: 5G has link connection. Off: 5G has no link connection.
LAN1/LAN2/LAN3	Flicker: LAN1/LAN2/LAN3 interfaces have forwarding data access. Off: LAN1/LAN2/LAN3 interfaces do not forward data access.
WAN	Flicker: WAN interfaces have forwarding data access. Off: WAN interfaces do not forward data access.
MESH	On: Mesh networking is successful. Off: There is no device in Mesh networking.

3. Network Application


PoE Power

Power and data transfer functions are performed over a single cable, eliminating the need to deploy power outlets for devices such as cameras.



Wireless mesh networking

Provide whole-home Wi-Fi coverage and eliminate weak signals once for all.




4. Login Method



Please connect devices according to the above topology.

Follow the steps for quick Router configuration, using the initial setup wizard:
Step 1 Connect your PC to the device via Ethernet or Wireless.
Note: Default WiFi name: Wi-Tek-XXXX, Password: 88888888

Step 2 To log in to the router, launch a web browser and enter 192.168.1.88 in the address. The login page will appear. By default, both the username and password are admin.



5. Configuration Steps

1)On the start page of the setup wizard, click **Next**.



2)When the device is connected to the Internet, you can set three options: PPPoE, DHCP Client, and Static IP, and then click **Next**.




3)For the WiFi page, you can select the country code and configure SSID, encryption, key. Also, choose whether to enable guest WiFi. Click **NEXT**.




6. Cloud Management Settings


2)Fill in the group name and location, and click save.



3)And click next.



4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

7. Warranty Card

4)Click the **COMPLETE** button to complete the setting.



5)The following page will appear after the configuration is complete. Make sure your device is connected to the internet.



After the login is successful, the steps to bind the device to the cloud account are as follows:


1) Click ADD NETWORK




Technical Support:tech@wireless-tek.com

8. Cloud Management Settings


2)Fill in the group name and location, and click save.



3)And click next.




4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

9. Cloud Management Settings

2)Fill in the group name and location, and click save.



3)And click next.




4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

10. Cloud Management Settings


2)Fill in the group name and location, and click save.



3)And click next.



4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

11. Cloud Management Settings


2)Fill in the group name and location, and click save.



3)And click next.




4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.



Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

12. Cloud Management Settings


2)Fill in the group name and location, and click save.



3)And click next.




4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

13. Cloud Management Settings


2)Fill in the group name and location, and click save.



3)And click next.




4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

14. Cloud Management Settings


2)Fill in the group name and location, and click save.



3)And click next.




4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

15. Cloud Management Settings

2)Fill in the group name and location, and click save.



3)And click next.




4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.




Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

16. Cloud Management Settings

2)Fill in the group name and location, and click save.



3)And click next.



4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.



Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

17. Cloud Management Settings

2)Fill in the group name and location, and click save.



3)And click next.



4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.



Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.

18. Cloud Management Settings

2)Fill in the group name and location, and click save.



3)And click next.



4)Enter the serial number, click ADD to create and click FINISH, the configuration is complete.



Note: The 17-digit SN code of the Add device is shown on the sticker on the back of the device.



Wireless-Tek Technology Limited
Address: Biaofang Technology Building 402, Bao'an street,
Baoan District, Shenzhen City, Guangdong, China
Website:www.wireless-tek.com
Tel:86-0755-32811290
Email:sales@wireless-tek.com
Technical Support:tech@wireless-tek.com

